

INSTALLATION INSTRUCTION

LED COB HOTEL DOWNLIGHT



TECHNICAL DATA:

Model	Watts	Lumens	BeamAngle	PF	CRI	Operation Temperature	Input Power	Dimension	Cutting Size
VT-2907	6	400	0-27°	0.6	>95	-20°C to +45°C	AC:220-240V,50Hz	Ø65x82mm	Ø55mm
VT-2911	10	650	0-27°	0.6	>95	-20°C to +45°C	AC:220-240V,50Hz	Ø85x96mm	Ø75mm
VT-2916	15	1000	0-27°	0.6	>95	-20°C to +45°C	AC:220-240V,50Hz	Ø105x113mm	Ø95mm
VT-2936	35	2300	0-27°	0.6	>95	-20°C to +45°C	AC:220-240V,50Hz	Ø160x176mm	Ø150mm

INTRODUCTION & WARRANTY


Thank you for selecting and buying V-TAC product. V-TAC will serve you the best. Please read these instructions carefully before starting the installation and keep this manual handy for future reference. If you have any another query, please contact our dealer or local vendor from whom you have purchased the product. They are trained and ready to serve you at the best. The warranty is valid for 5 years from the date of purchase. The warranty does not apply to damage caused by incorrect installation or abnormal wear and tear. The company gives no warranty against damage to any surface due to incorrect removal and installation of the product. The products are suitable for 10-12 Hours Daily operation. Usage of product for 24 Hours a day would void the warranty. This product is warranted for manufacturing defects only.

WARNING!

1. Please make sure to turn off the power before starting the installation.
2. The light source of this luminaire is not replaceable, when the light source reaches its end of life the whole luminaire should be replaced.
3. Install only by certified Electrician.



This marking indicates that this product should not be disposed of with other household wastes.



Caution, risk of electric shock.

INSTALLATION INSTRUCTIONS

1

Switch off the power before starting the installation
Cut a hole in the ceiling according to the cutting size

2

Separate the embedded part from the lamp.

3

Rotate the embedded part clockwise to keep it close to the ceiling.

4

Connect the wire of lamp and the driver.

5

Adjust the angle before inserting the lamp into the ceiling.

6

Push the lamp body insert to the embedded part. Make sure lamp is firmly installed before switch on the power.